

950

**ISP**<sup>®</sup>


International Sound Products



# *service* *manual*







**ELECTRO-DENIS** s.r.l.  
Radio-TV-HiFi-Electro Ménager  
Faubourg de France 2  
6830 Bouillon  
061 - 466 352

**P. U.**  
**Tuner**  
**Amplifier**  
**Cassette-deck**  
**SERIE 700**










SW FUNCTION

SW301	REC/PLAY SW	POLY POS
SW302	REC/PLAY SW	POLY POS
SW303	Beat SW	
SW304	NOX/CR02/Metal SW	NO POS
SW305	NOX/CR02/Metal SW	NO POS
SW306	DoI SW	OFF POS
SW307	Muting SW	OFF POS
SW308	LEAF SW	OFF POS

HRP-075



HEADPHONE JACK  
J402

SPEAKER (4~16Ω)  
J403


SW FUNCTION  
SW401-1 ~ 401-5 PHONO  
TUNER  
PLAY  
TAPE

OP-980  
PCB 3


OP-981  
PCB 4


POWER TRANS  
T301

SW FUNCTION  
SW501 REC/PLAY SW PLAY POS  
SW502  
SW503 BATT SW  
SW504 NRY/CHOL/METAL SW NO POS  
SW505  
SW506 Del SW OFF POS  
SW507 Muting SW OFF POS  
SW508 LEAF SW OFF POS




IPO-UT






PCE 1






Dolby

07-010






DolBy  
978-90

Type 45

TOP VIEW  
FCB 2

Serie 700-4

OP-980



VOLUME


BLANCE

TREBLE

12 11 10 9 8 7 6 5 4 3 2 1 J4

DP-980

J8  
3 2 1



BLANCE


TREBLE

BASS




HEAD

12	11	10	9	8	7	6	5	4	3	2	1
----	----	----	---	---	---	---	---	---	---	---	---


J4



Serie 700-5



Serie 700-6




TOP VIEW

PCB5



### TAPE SECTION



### TUNER SECTION

